

# SOFTWARE MANUAL

VERSION 1.2



# S-2

**METAPACE**

Copyright © 2010-2012 EQUATOR LIMITED  
All rights reserved.

All intellectual property rights are the property of their owners. EQUATOR LIMITED is authorized the right to use the software; it is provided under a license agreement containing restrictions on use and disclosure and is also protected by copyright law. Reverse engineering of the software is prohibited.

Due to continued product development this information may change without notice. The information and intellectual property contained herein is confidential between EQUATOR and the client and remains the exclusive property of EQUATOR LIMITED and other third party. If you find any problems in the documentation, please report them to us in writing. EQUATOR does not warrant that this document is error-free.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise without the prior written permission of EQUATOR LIMITED.

For product consultancy and technical support, please contact your local sales representative. Also, you may visit our web site for more information.

The EQUATOR logo is a registered trademark of EQUATOR LIMITED.

All brand, product and service, and trademark names are the property of their registered owners.

The editorial use of these names is for identification as well as to the benefit of the owners, with no intention of infringement.

**EQUATOR LIMITED**  
Website: <http://www.metapace.com>

# RELEASE NOTES

---

Version	Date	Notes
1.20	July 4, 2012	<ul style="list-style-type: none"><li>▶ Modify: Remove Read Scanner Settings item to Tools Tab</li><li>▶ Modify: Modify all illustrations</li><li>▶ Modify: 1.2 Power management - LED status for Bluetooth connection</li><li>▶ Modify: Page 8 Read Scanner Settings and Download Scanner Settings</li><li>▶ Modify: 2.2.1 Baud Rate default to 115200</li><li>▶ New: Add 2.2.9 and 2.4.6 ACK/NAK Error Beep</li><li>▶ New: Add 5.2.2 Pause Field Time (sec)</li></ul>
1.10	Jun. 29, 2010	Initial Release

# CONTENTS

---

<b>RELEASE NOTES .....</b>	<b>- 3 -</b>
<b>INTRODUCTION .....</b>	<b>1</b>
Using Metapace S-2 Software .....	2
How to Configure the Scanner? .....	3
Setup Barcodes .....	4
Scanner Information .....	6
Menu Bar.....	7
File Menu .....	7
Configure Menu .....	7
Tools Menu .....	8
Help Menu.....	9
Toolbar .....	10
<b>CHANGING SCANNER SETTINGS .....</b>	<b>11</b>
1.1 Scanning Mode .....	12
1.1.1 Scanning Timeout.....	14
1.1.2 Continuous Mode Decode Delay .....	14
1.1.3 Aiming Timeout.....	14
1.1.4 Re-read Delay .....	14
1.1.5 Read Redundancy .....	15
1.1.6 Addon Security for UPC/EAN .....	15
1.2 Power Management.....	16
1.2.1 Auto Power Off .....	17
1.2.2 Power-Saving .....	17
1.2.3 Low Battery Alarm .....	17
1.3 Status Indicator.....	18
1.3.1 Beeper Volume .....	18
1.3.2 Good Read Beep.....	18
1.3.3 Good Read LED.....	18
1.4 "No Read" Support (Send "NR" to Host) .....	18
1.5 Read Negative Barcode.....	18
1.6 CCD Always Active.....	18
1.7 Auto Sense .....	19
1.8 Memory Mode .....	19
1.8.1 Data Delay.....	19
1.8.2 Send Data & Clear Memory .....	19
1.9 Effective Decoding Area .....	20
1.10 Transmit Buffer .....	20
<b>SELECTING OUTPUT INTERFACE .....</b>	<b>21</b>
2.1 Keyboard Wedge.....	22
2.1.1 Keyboard Type .....	22
2.1.2 Alternate Composing.....	23

2.1.3 Alphabets Transmission .....	23
2.1.4 Digits Transmission .....	24
2.1.5 Capital Lock Type.....	24
2.1.6 Capital Lock State .....	24
2.1.7 Alphabets Layout .....	25
2.1.8 Digits Layout .....	26
2.1.9 Laptop Support .....	26
2.1.10 Inter-Function Delay .....	26
2.1.11 Inter-Character Delay .....	27
2.1.12 Sniff Mode (via Cradle) .....	27
2.2 RS-232.....	28
2.2.1 Baud Rate .....	28
2.2.2 Data Bits .....	28
2.2.3 Parity .....	29
2.2.4 Stop Bit.....	29
2.2.5 Flow Control .....	29
2.2.6 Inter-Function Delay .....	29
2.2.7 Inter-Character Delay .....	29
2.2.8 ACK/NAK Timeout .....	29
2.2.9 ACK/NAK Error Beep.....	30
2.2.10 Sniff Mode (via Cradle) .....	30
2.3 Bluetooth HID .....	31
2.3.1 Keyboard Type .....	31
2.3.2 Keyboard Settings.....	32
2.3.3 Inter-Function Delay .....	32
2.3.4 Inter-Character Delay .....	32
2.3.5 Authentication .....	32
2.3.6 Broadcasting.....	34
2.3.7 Sniff Mode.....	34
2.3.8 Character Transmit Mode .....	34
2.4 Bluetooth SPP Slave Mode.....	35
2.4.1 Authentication .....	35
2.4.2 Device Name Broadcasting .....	36
2.4.3 Sniff Mode.....	37
2.4.4 Inter-Function Delay .....	37
2.4.5 ACK/NAK Timeout .....	37
2.4.6 ACK/NAK Error Beep.....	37
2.5 Bluetooth SPP Master Mode .....	38
2.6 USB HID .....	40
2.7 USB Virtual COM .....	41
<b>CHANGING SYMBOLOGY SETTINGS .....</b>	<b>43</b>
3.1 Codabar .....	45
3.2 Code 25 – Industrial 25 .....	46
3.3 Code 25 – Interleaved 25.....	47
3.4 Code 25 – Matrix 25 .....	47
3.5 Code 39 .....	48
3.6 Code 93 .....	48
3.7 Code 128.....	48

3.8 EAN-8 .....	49
3.9 EAN-13 .....	50
3.10 GS1-128 (EAN-128) .....	51
3.11 ISBT 128 .....	51
3.12 MSI .....	52
3.13 French Pharmacode .....	53
3.14 Italian Pharmacode .....	53
3.15 Plessey .....	54
3.16 GS1 DataBar (RSS Family) .....	55
3.17 Telepen .....	57
3.18 UPC-A .....	58
3.19 UPC-E .....	59
<b>DEFINING OUTPUT FORMAT .....</b>	<b>61</b>
4.1 Letter Case .....	62
4.2 Character Substitution .....	63
4.2.1 Applicable Code Types .....	64
4.3 Prefix/Suffix Code .....	65
4.4 Code ID .....	66
4.4.1 Code ID Set 1~5 .....	67
4.4.2 Change Code ID .....	68
4.4.3 Clear .....	68
4.5 Code Length .....	69
4.6 Output Sequence (Multi-Barcode Editor) .....	70
4.7 Remove Special Character .....	72
<b>APPLYING EDITING FORMATS .....</b>	<b>73</b>
5.1 Format Selection .....	74
5.1.1 Enable Editing Formats .....	74
5.1.2 Exclusive Data Editing .....	74
5.2 Configure Editing Format .....	75
5.2.1 Applicable Conditions .....	75
5.2.2 Field Settings .....	76
5.2.3 Transmission Sequence .....	78
5.2.4 Examples .....	79
<b>GRID CONTROL .....</b>	<b>83</b>
Original Grid Control .....	83
Special Grid Control for Keyboard Interface .....	84
Grid Control — Normal Key .....	84
Grid Control — Scan Code .....	85

# INTRODUCTION

---


The software is a convenient utility that helps you configure the Metapace S-2 scanner. It provides two ways to change or update your scanner configuration – (1) download the new settings directly to the scanner, and (2) print out the setup barcodes that can be read by the scanner anytime anywhere, in order to load new settings or restore defaults.

This manual contains information on using the software. We recommend that you read it thoroughly before use and keep it at hand for quick reference.

Thank you for choosing our product!

## USING METAPACE S-2 SOFTWARE

The Metapace S-2 software package includes two programs, **Metapace S-2.exe** and **PrintBarcode.exe**, which can be used to configure the Metapace S-2 scanner. First, run **Metapace S-2.exe** on your computer. You may configure its settings by (A) starting a new configuration, (B) opening an existing configuration file, or (C) reading configuration from a scanner. Then, download the current configuration to the rest of your Metapace S-2 scanners directly, or generate a file named *Barcode.prn* to keep a copy of the setup barcodes for the current configuration.




Note: If you wish to keep the Barcode.prn file, you must rename it; otherwise, it will be automatically overwritten as long as you choose to generate setup barcodes. Once you have a \*.prn file, you can print the setup barcodes at any time by running PrintBarcode.exe.




## HOW TO CONFIGURE THE SCANNER?

- 1) Run **Metapace S-2.exe** on your computer.
- 2) If you are using **Metapace S-2.exe** for the first time, click to expand the [Scanner Information](#) by category so that the default settings of the scanner can be viewed.



- 3) To create a new configuration file, click  or  on the toolbar.

To open an existing configuration file, click  on the toolbar.


To clone configuration from another scanner, click **Tools | Read Scanner Settings**. This scanner has to be connected to the host computer via RS-232 or Virtual COM (BT SPP or USB VCOM).

Note: If you are using USB Virtual COM for the first time, you must install its driver from the CD-ROM. Driver version 5.3 or later is required. Please remove older versions!

- 4) Proceed to configure the scanner. The data process is illustrated below.



1. The scanner will work with the settings specified on the Scanner tab.
2. It will read barcodes only if their symbologies are enabled, and output data in the desired letter case as selected on the Symbology tab.
3. It will check one by one whether the read barcode meets the criteria set out for a concatenation of barcodes on the Output Sequence tab.
4. It will perform character substitution as defined on the Format Editing tab.


5. It will add 2-digit length code to desired symbologies as selected on the Code Length tab.
  6. It will add 1- or 2-character identifier to desired symbologies as selected on the Code ID tab.
  7. It will apply editing formats on desired symbologies that meet the criteria set out on the Format Editing tab.
  8. It will add prefix/suffix code to enabled symbologies as selected on the Symbology tab.
  9. Finally, it will output data via the desired interface.
- 5) If the scanner is connected to the host computer via RS-232 or Virtual COM (BT SPP or USB VCOM), you can directly download the settings. Otherwise, you can click  to print out setup barcodes and load settings to the scanner by reading setup barcodes.

Note: The program PrintBarcode.exe must be in the same folder of **Metapace S-2.exe**.

- 6) When the scanner is configured successfully, connect it to the host computer via a proper interface: Keyboard wedge, RS-232, Bluetooth HID, Bluetooth SPP, USB HID, or USB Virtual COM.


## SETUP BARCODES

If you want to restore default settings, scan these barcodes one by one.



Setup Barcodes	Indication
<i>Enter Setup</i>	Scan this barcode to enter the configuration mode – <ul style="list-style-type: none"> <li>▶ it will respond with six beeps (high-low tone repeats three times), and</li> <li>▶ the LED indicator will become flashing red</li> </ul>
<i>Restore Default Settings</i>	Scan this barcode to restore the default settings. When the scanner has successfully read the barcode – <ul style="list-style-type: none"> <li>▶ it will respond with two beeps (low-high tone)</li> </ul>
<i>Update</i>	Scan this barcode to confirm the updating – <ul style="list-style-type: none"> <li>▶ it will respond with six beeps (high-low tone repeats three times), and</li> <li>▶ the LED indicator will go off.</li> </ul> <p>When the scanner has successfully updated the settings, it will restart itself and respond with one long beep.</p>


If you want to load new settings, scan associated barcodes. Take the screenshot below for example.



- ▶ You can always restore the default settings.
- ▶ The setup barcodes are categorized into groups of related settings, such as Scanner Settings, Prefix/Suffix Settings, Interface Settings, Code ID Settings, etc.
- ▶ After having made any changes to settings, you need to scan the "Update" barcodes to confirm such action. However, if a decimal or hexadecimal value is involved in the setting, you need to scan the "Validate" barcode before the "Update" barcode.

## SCANNER INFORMATION


After selecting the scanner, click to expand the scanner information by category so that the default settings of the scanner can be viewed. If you open an existing configuration file or change the current settings, they will be updated accordingly.



## MENU BAR


The menu bar contains a number of menus that specify which task you want the system to perform. Each menu contains a list of commands. Some of the options carry out commands immediately, and others display a window so that you can enter additional information. If an option is followed by [...], it will display a window. Otherwise, the command is carried out immediately.

## FILE MENU




Command	To Do...
<i>New</i>	To create a new configuration file.
<i>Open</i>	To open an existing configuration file. File path needs to be specified.
<i>Save</i>	To save the current settings.
<i>Save As</i>	To save the current settings to a new configuration file.
<i>Exit</i>	To close the program.

## CONFIGURE MENU



Command	To Do...
<i>Configure Scanner</i>	<p>Configure the current settings for the target scanner.</p> <p>Refer to the following sections –</p> <ul style="list-style-type: none"> <li>▶ <a href="#">Chapter 1 – Changing Scanner Settings</a></li> <li>▶ <a href="#">Chapter 2 – Selecting Output Interface</a></li> <li>▶ <a href="#">Chapter 3 – Changing Symbology Settings</a></li> <li>▶ <a href="#">Chapter 4 – Defining Output Format</a></li> <li>▶ <a href="#">Chapter 5 – Applying Editing Formats</a></li> </ul>


## TOOLS MENU



Command	To Do...
<i>Read Scanner Settings</i>	<p>Display [COM Port Properties] dialog box that enables users to fetch the settings applied on the scanner at the moment. It also supports to fetch user's defined settings (= "<b>User Defaults</b>").</p> <div data-bbox="421 1120 920 1830" data-label="Image"> </div> <ul style="list-style-type: none"> <li>▶ A dialog box pops up for configuring the COM port properties on your PC. For Bluetooth SPP or USB Virtual COM, specify the COM port for connection and ignore the other settings.</li> </ul>

**Download  
Scanner Settings**

Display the [COM Port Properties] dialog box that enable users to send the settings made in the Utility to the target scanner when the scanner is connected to your PC via RS-232 or Virtual COM (Bluetooth SPP or USB VCOM). It also supports you to send the settings to the scanner as **"User Defaults"**.



- ▶ The [COM Port Properties] dialog box provides the access to set the COM port properties on your PC. For Bluetooth SPP or USB Virtual COM, specify COM port for connection and ignore the other settings.


**Print  
Scanner Settings**

Run PrintBarcode.exe to print out the [Setup Barcodes](#), which will be automatically saved in the Barcode.prn file.

If the scanner is not connected to the host computer via RS-232 or Virtual COM (BT SPP or USB VCOM), scanner configuration can be changed by scanning the setup barcodes.

- ▶ The setup barcodes are categorized into groups of related settings.

Note: To clone settings, first read settings from a specific scanner, and then download these settings to other scanners.

**HELP MENU**







Command	To Do...
About Metapace S-2	Provide version information of the software.

## TOOLBAR

The toolbar allows quick access to most commands.



From left to right, the icons stand for the following commands:

	► New
	► Open
	► Save
	► Configure
	► Print
	► Download Settings




# Chapter 1

## CHANGING SCANNER SETTINGS

---

You may configure scanner settings of the target scanner.



The image shows a 'Scanner Settings' dialog box with a blue title bar and standard Windows window controls. The 'Scanner' tab is selected and highlighted with a red rectangle. The dialog contains various settings for a scanner, organized into two columns. The settings include Scanning Mode (Laser), Reading Redundancy (None), Re-read Delay (0.4 sec), Continuous Mode Decode Delay (None), Aiming Timeout (1 sec), Scanning Timeout (10 sec), Auto Power Off (10 min), Good Read Beep Freq (4 KHz), Good Read Beep Len (Shortest), Beeper Volume (Max), Low Battery Alarm (Enable), Power Saving Duration (2 min), Read Negative Barcode (unchecked), NO READ Support (unchecked), CCD Always Active (checked), Auto Sense (Normal), Good Read LED (4 x 10 ms), Memory Mode (unchecked), Data Delay (None), Centering Window (unchecked), Left Half (Left 50%), Right Half (Right 50%), and Transmit Buffer (checked). There are 'Reset', 'OK', and 'Cancel' buttons at the bottom.

Setting	Value	Option
Scanning Mode	Laser	Dropdown
Reading Redundancy	None	Dropdown
Re-read Delay	0.4 sec	Dropdown
Continuous Mode Decode Delay	None	Dropdown
Aiming Timeout	1	Spinner (sec)
Scanning Timeout	10	Spinner (sec)
Auto Power Off	10	Spinner (min)
Good Read Beep Freq	4 KHz	Dropdown
Good Read Beep Len	Shortest	Dropdown
Beeper Volume	Max	Dropdown
Low Battery Alarm	Enable	Dropdown
Power Saving Duration	2	Spinner (min)
Read Negative Barcode		<input type="checkbox"/>
NO READ Support		<input type="checkbox"/>
CCD Always Active		<input checked="" type="checkbox"/>
Auto Sense	Normal	Dropdown
Good Read LED	4	Spinner (x 10 ms)
Memory Mode		<input type="checkbox"/>
Data Delay	None	Dropdown
Centering Window		<input type="checkbox"/>
Left Half	Left 50%	Dropdown
Right Half	Right 50%	Dropdown
Transmit Buffer		<input checked="" type="checkbox"/>

## IN THIS CHAPTER

1.1 Scanning Mode .....	12
1.2 Power Management .....	16
1.3 Status Indicator .....	18
1.4 "No Read" Support (Send "NR" to Host) .....	18
1.5 Read Negative Barcode .....	18
1.6 CCD Always Active .....	18
1.7 Auto Sense .....	19
1.8 Memory Mode .....	19
1.9 Effective Decoding Area .....	20
1.10 Transmit Buffer .....	20

### 1.1 SCANNING MODE

Different scan modes are supported – select the scan mode that best suits the requirements of a specific application. Refer to the comparison table below.

Scan Mode	Start to Scan				Stop Scanning			
	<i>Always</i>	<i>Press trigger once</i>	<i>Hold trigger</i>	<i>Press trigger twice</i>	<i>Release trigger</i>	<i>Press trigger once</i>	<i>Barcode being read</i>	<i>Timeout</i>
<i>Continuous mode</i>	✓							
<i>Test mode</i>	✓							
<i>Laser mode</i>			✓		✓		✓	✓
<i>Auto Off mode</i>		✓					✓	✓
<i>Auto Power Off mode</i>		✓						✓
<i>Aiming mode</i>				✓			✓	✓
<i>Multi-Barcode mode</i>			✓		✓			
<i>Alternate mode</i>		✓				✓		

Note: By default, the scan mode is set to Laser mode.

### Continuous Mode

The scanner is always scanning.

- ▶ To decode the same barcode repeatedly, move away the scan beam and target it at the barcode for each scanning.

---

Note: Refer to "Decode Delay" and "Delay between Re-read".

---

### Test Mode

The scanner is always scanning.

- ▶ Capable of decoding the same barcode repeatedly, for testing purpose.

### Laser Mode

The scanner will start scanning once the trigger is hold down.

- ▶ The scanning won't stop until (1) a barcode is decoded, (2) the pre-set timeout expires, or (3) you release the trigger.

---

Note: Refer to "Scanning Timeout".

---

### Auto Off Mode

The scanner will start scanning once the trigger is pressed.

- ▶ The scanning won't stop until (1) a barcode is decoded, and (2) the pre-set timeout expires.

---

Note: Refer to "Scanning Timeout".

---

### Auto Power Off Mode

The scanner will start scanning once the trigger is pressed.

- ▶ The scanning won't stop until the pre-set timeout expires, and, the pre-set timeout period re-counts after each successful decoding.

---

Note: Refer to "Delay between Re-read" and "Scanning Timeout".

---

### Aiming Mode

The scanner will aim at a barcode once the trigger is pressed, and start scanning when the trigger is pressed again within one second.

- ▶ The scanning won't stop until (1) a barcode is decoded, (2) the pre-set timeout expires, or (3) you release the trigger.

---

Note: Refer to "Aiming Timeout".

---

#### Multi-Barcode Mode

The scanner will be scanning as long as the trigger is held down, capable of decoding not only one single barcode but a concatenation of unique barcodes.

- ▶ The scanning won't stop until you release the trigger.

Note: (1) A barcode is considered unique when its Code Type or data is different from others. (2) Multi-Barcode Mode has nothing to do with the Multi-Barcode Editor.

#### Alternate Mode

The scanner will start scanning once the trigger is pressed.

- ▶ The scanning won't stop until you press the trigger again.

### 1.1.1 SCANNING TIMEOUT

Specify the scanning time interval (1~254 sec.; 0= disable) when the scan mode is set to any of the following –

- ▶ Laser mode
- ▶ Auto Off mode
- ▶ Auto Power Off mode
- ▶ Aiming mode

### 1.1.2 CONTINUOUS MODE DECODE DELAY

Set the time interval between each decoding when in Continuous Mode.

### 1.1.3 AIMING TIMEOUT

You can limit the aiming time interval (1~15 sec.) when in Aiming Mode. By default, the scanner time-out is set to 1 second.

### 1.1.4 RE-READ DELAY

This is also referred to as the “Blocking Time”, which is used to prevent the scanner from accidentally reading the same barcode twice when the scan mode is set to any of the following –

- ▶ Continuous mode
- ▶ Auto Power Off mode
- ▶ Alternate mode

### 1.1.5 READ REDUNDANCY

Select the level of reading security. For example,

- ▶ If "No Redundancy" is selected, one successful decoding will make the reading valid and induce the "READER Event".
- ▶ If "Three Times" is selected, it will take a total of four consecutive successful decodings of the same barcode to make the reading valid. The higher the reading security is (that is, the more redundancy the user selects), the slower the reading speed gets.

It is obvious that the more redundancy you select, the higher the reading security is, and thus, the slower the reading speed becomes. You will have to compromise between reading security and decoding speed.

### 1.1.6 ADDON SECURITY FOR UPC/EAN

This option is available on the Symbology tab. You may like to enforce read redundancy (1~30 times; 0= disable) on UPC/EAN barcodes with addons only.

---

Note: UPC/EAN Addon 2 and Addon 5 must be enabled individually for this setting to take effect.

---

## 1.2 POWER MANAGEMENT

The scanner will stay active at power-on, which may be followed by a transition from full CPU speed to low CPU speed ([1.2.2 Power-Saving](#)) to auto shutdown([1.2.1 Auto Power Off](#)).

### Before establishing a WPAN connection successfully...

---

1. The scanner will stay active for a specified period of time (2 minutes by default) for the following scenarios. Its CPU is running at full speed, and the LED is flashing blue (On/Off ratio 0.5 s: 0.5 s).
  - (a) waiting for a connection request from the host (Bluetooth SPP Slave Mode)
  - (b) trying to connect to the host (Bluetooth HID or SPP Master Mode)
  - (c) trying to connect to the cradle
2. If it fails to connect within 2 minutes, the scanner will become inactive to save power for the remaining period of time (the specified value minus 2 minutes). Its CPU is running at low speed, and the LED is flashing red (On/Off ratio 0.3 s: 2.5 s).

Press the trigger to wake up the scanner when it becomes inactive, and the scanner will stay active again.
3. If it fails to connect again and again, and finally stays inactive until the specified time interval has elapsed, the scanner will automatically turn off in order to conserve battery power.

Hold down the trigger for about 2 seconds to turn it on. For scenarios (a) and (b) in step 1, on your computer you will have to search for the scanner again.

### After establishing a WPAN connection successfully...

---

Once a WPAN connection is established successfully, the LED is solid blue. If the scanner is idle during the specified time interval for Auto Power Off, it will automatically turn off when the time is up. You will hear three short beeps, tone descending from high to low. For Bluetooth HID or SPP, there is no transition from full CPU speed to low CPU speed. However, when connecting to the cradle, the scanner will go through the transition in order to save power.

- ▶ For Bluetooth HID, the scanner will resume connection with the host upon powering on again, as long as the host application is running. You will hear three short beeps, tone ascending from low to high. If the scanner fails to resume connection, it will try every 5 seconds to re-connect to the host unless you have the scanner read the "Reset Connection" label.
- ▶ For Bluetooth SPP Slave Mode, the scanner must wait for the host to re-connect.
- ▶ For Bluetooth SPP Master Mode, the scanner will resume connection with the host upon powering on again, as long as the host application is running. You will hear three short beeps, tone ascending from low to high. If the scanner fails to resume connection, it will try every 5 seconds to re-connect to the host unless you have the scanner read the "Reset Connection" or "Restore System Defaults" label.
- ▶ With the use of cradle, the scanner will try re-connecting to the cradle unless you turn off the scanner.

### 1.2.1 AUTO POWER OFF

Specify the time interval (1~254 min.; 0= disable) before the scanner automatically shuts down. By default, the scanner will stay active for 10 minutes for the said scenarios.

---

Note: Auto Power Off will not take effect when the scanner is in Auto-Sense mode and seated in the Auto-Sense Stand.

---

### 1.2.2 POWER-SAVING

Specify the time interval (1~254 min.; 0= disable) before the scanner enters low-speed mode for power-saving. By default, the scanner will stay active for 2 minutes for the said scenarios.

---

Note: Power-Saving will not take effect when one of the following conditions is met:

- (1) the scanner has already established a Bluetooth HID/SPP connection,
- (2) the scan mode is set to Test, Continuous or Alternate Mode,
- (3) the scanner is in Auto-Sense mode and seated in the Auto-Sense Stand, or
- (4) the setting value of Power-Saving is greater than that of Auto Power Off.

---

### 1.2.3 LOW BATTERY ALARM

By default, the low battery alarm is enabled. When the battery level drops below 3.4 V, the scanner will respond with a warning beep.

## 1.3 STATUS INDICATOR

### 1.3.1 BEEPER VOLUME

Beeping is used to indicate various kinds of conditions, such as Good Read, buffer full status, configuration status, etc. Select a suitable volume.

### 1.3.2 GOOD READ BEEP

Good Read Beep is always enabled. By default, beeper frequency is set to 4 KHz and duration is set to shortest. Select a different frequency and duration if necessary.

### 1.3.3 GOOD READ LED

By default, Good Read LED is enabled and its duration is set to 40 milliseconds. When reading a barcode successfully, the LED on the scanner will become solid green and go off quickly. Enter a value, ranging from 1 to 254, in units of 10 milliseconds.

## 1.4 "NO READ" SUPPORT (SEND "NR" TO HOST)

The scanner will send the "NR" string to the host to notify the No Read event.

## 1.5 READ NEGATIVE BARCODE

Normally, barcodes are printed with the color of the bars darker than that of the spaces. But for negative barcodes, they are printed in the opposite sense just like negative films. The spaces of negative barcodes are printed with a color darker than that of the bars. You can configure the scanner to be able to read negative barcodes.

## 1.6 CCD ALWAYS ACTIVE

This feature is used to keep the CCD sensor always active so that the scanner can decode more efficiently.




## 1.7 AUTO SENSE

When the scanner is seated in the cradle, press the trigger so that it will automatically enter Auto-Sense mode. In Auto-Sense mode, it will force the scanner to apply Laser mode as the scan mode. However, it works differently from the original Laser mode. Now the scanner will be scanning as long as it is seated in the cradle, as shown below. Whenever a barcode is brought within range, the scanner will be able to decode it.

When the ambient light is too dim to activate the sensor, you may change the sensitivity from "Normal" to "High" to improve performance.

**Note:** Remove the scanner from the cradle to exit Auto-Sense mode. It will return to Laser mode. If Laser mode is not desired, proceed to select a scan mode best suits your application.



**Note:** For Auto-Sense mode to work, you must connect (1) the power supply cord and (2) the interface cable to the Auto-Sense Stand.

## 1.8 MEMORY MODE

By default, memory mode is disabled. When the scanner is set to memory mode, it means a WPAN connection is disabled.

- ▶ The scanner keeps 512 KB flash memory for memory mode operation.

### 1.8.1 DATA DELAY


You may set a delay between each data record while transmitting data back to the server.

### 1.8.2 SEND DATA & CLEAR MEMORY

When flash memory is run out, the scanner will respond with two short beeps (high-low tone) as a warning. You are advised to send data to the server immediately by having the scanner read the setup barcodes. The scanner will resume the previous WPAN connection with the host computer temporarily. Refer to a separate manual.

## 1.9 EFFECTIVE DECODING AREA

By default, the effective decoding area is 100% covered by the scanned area. However, you may narrow down the decoding area to prevent reading the wrong barcode when a number of barcodes are printed closely. The scanner will only read barcodes that appear in the effective decoding area. Select the check box of "Centering Window" and select the percentage to narrow down the decoding area. For example, read "Left 10%" and then "Right 30%" for the scanner to decode barcode "A" only.



## 1.10 TRANSMIT BUFFER

By default, transmit buffer is enabled and for use when the scanner is out of range. Upon reading a barcode successfully within range, the scanner responds with one short beep (high tone) and its LED indicator becomes solid green and goes off quickly. However, the host computer may not receive the data immediately if getting out of range.

- ▶ The scanner comes with 4 KB transmit buffer. It can ignore the transmission status and keep on reading barcodes until the buffer is full.

### Transmit Buffer Enabled

- ▶ When transmit buffer is enabled and the scanner is out of range, the scanner will respond with two short beeps, high-low tone, upon reading a barcode successfully.
- ▶ When transmit buffer is full, the scanner will respond with one long beep (low tone) and its LED indicator will become solid red and go off quickly. You are advised to get back to range.

### Transmit Buffer Disabled

- ▶ When transmit buffer is disabled and the scanner is out of range, the scanner will respond with one long beep (low tone). You are advised to get back to range.

## SELECTING OUTPUT INTERFACE

---

By default, the output interface is set to "Bluetooth HID". In order to establish a proper connection between your computer and the scanner, we suggest that you follow these instructions –

- 1) Install batteries and hold down the trigger for about 2 seconds to turn on the scanner.
- 2) Turn on your computer or laptop and establish a WPAN connection with the scanner

It also allows connecting the RS-232 or Keyboard Wedge cable via the cradle.

---

Note: If using the RS-232 cable, join the power supply cord.

---


### IN THIS CHAPTER

---

2.1 Keyboard Wedge.....	22
2.2 RS-232.....	28
2.3 Bluetooth HID .....	31
2.4 Bluetooth SPP Slave Mode .....	35
2.5 Bluetooth SPP Master Mode .....	38
2.6 USB HID .....	40
2.7 USB Virtual COM .....	41

## 2.1 KEYBOARD WEDGE

Use the "Y-shaped" keyboard wedge cable to connect the cradle between the keyboard input port of the host computer and the keyboard. The scanned data will be transmitted to the host keyboard port as if it is manually entered via the keyboard.



### 2.1.1 KEYBOARD TYPE

By default, the keyboard type is set to PCAT (US). The following keyboard types are supported –

No.	Keyboard Type	No.	Keyboard Type
1	PCAT (US)	16	PS55 001-2
2	PCAT (French)	17	PS55 001-82
3	PCAT (German)	18	PS55 001-3
4	PCAT (Italian)	19	PS55 001-8A
5	PCAT (Swedish)	20	PS55 002-1, 003-1


6	PCAT (Norwegian)	21	PS55 002-81, 003-81
7	PCAT (UK)	22	PS55 002-2, 003-2
8	PCAT (Belgium)	23	PS55 002-82, 003-82
9	PCAT (Spanish)	24	PS55 002-3, 003-3
10	PCAT (Portuguese)	25	PS55 002-8A, 003-8A
11	PS55 A01-1	26	IBM 3477 Type 4 (Japanese)
12	PS55 A01-2 (Japanese)	27	PS2-30
13	PS55 A01-3	28	IBM 34XX/319X, Memorex Telex 122 Keys
14	PS55 001-1	29	User-Defined Table
15	PS55 001-81	30	PCAT (Turkish)

### 2.1.2 ALTERNATE COMPOSING

By default, Alternate key composing is disabled. Select [Yes] to allow emulating Alternate key code of a specific keyboard character. For example, [Alt] + [065] will be sent to host for the character "A" regardless the keyboard type you are using.


### 2.1.3 ALPHABETS TRANSMISSION

By default, the alphabets transmission is case-sensitive, meaning that the alphabets will be transmitted according to their original case, the status of Caps Lock on the keyboard, as well as the Capital Lock setting. Select [Ignore Case] to have alphabets transmitted according to the status of Caps Lock on the keyboard only.



### 2.1.4 DIGITS TRANSMISSION

By default, the alphanumeric keypad is used for transmitting digits. Select "Numeric Keypad" if you wish to use the keys on the numeric keypad.



Note: If you select "Numeric Keypad", the Num Lock status of the physical keyboard should be "ON".

### 2.1.5 CAPITAL LOCK TYPE

Cap Lock Type	Description
<i>Normal</i>	Normal type
<i>Capital Lock</i>	When enabled, the keys of alphabetic characters will be interpreted as capital letters. However, this does not affect the number or punctuation keys.
<i>Shift Lock</i>	When enabled, the keys of alphabetic characters will be interpreted as capital letters. In addition, this affects the number or punctuation keys.

### 2.1.6 CAPITAL LOCK STATE

In order to send the alphabets with correct case, the scanner needs to know the status of Caps Lock on the keyboard. Incorrect settings may result in reversed case of the alphabets being transmitted.

Capital Lock State	Description
<i>Capital Lock OFF</i>	Assuming that the status of Caps Lock on the keyboard is OFF, transmitted characters are exactly the same as in the barcode (when "case-sensitive" is selected for Alphabets Transmission).
<i>Capital Lock ON</i>	Assuming that the status of Caps Lock on the keyboard is ON, transmitted characters are exactly the same as in the barcode (when "case-sensitive" is selected for Alphabets Transmission). ▶ Refer to the Capital Lock Type above.

<i>Auto Detection</i>	The scanner will automatically detect the status of Caps Lock on the keyboard before data is transmitted; transmitted characters are exactly the same as in the barcode (when "case-sensitive" is selected for Alphabets Transmission).
-----------------------	---


### 2.1.7 ALPHABETS LAYOUT

By default, the alphabets layout is set to normal mode, also known as the standard English layout. Select French or German keyboard layout if necessary.

The scanner will make adjustments when sending the "A", "Q", "W", "Z", "Y", and "M" characters according to this setting.

#### US Keyboard Style – Normal


QWERTY layout, which is normally used in western countries.



- Select "Lower Row" for the "Digits Layout" setting for the upper row is for special characters.

#### French Keyboard Style – AZERTY


French layout; see below for French Keyboard Style.



- Select "Upper Row" for the "Digits Layout" setting for the lower row is for special characters.

### German Keyboard Layout – QWERTZ

German layout; see below for German Keyboard Style.



- Select "Lower Row" for the "Digits Layout" setting for the upper row is for special characters.

Note: This setting only works when the keyboard type selected is US keyboard, such as PCAT (US). The Alphabets Layout and Digits Layout setting must match your keyboard.

### 2.1.8 DIGITS LAYOUT

Select a proper layout that matches the alphabets layout. The scanner will make adjustments according to this setting.

Options	Description
<i>Normal</i>	Depends on the [Shift] key or [Shift Lock] setting
<i>Lower Row</i>	For QWERTY and QWERTZ keyboards
<i>Upper Row</i>	For AZERTY keyboards

Note: This setting is meant to be used with the Alphabets Layout, and perhaps the Character Substitution setting when support to certain keyboard types (languages) is unavailable but required.

### 2.1.9 LAPTOP SUPPORT

By default, laptop support is disabled. Select the check box if you connect the wedge cable to a laptop without an external keyboard being inter-connected.

### 2.1.10 INTER-FUNCTION DELAY

By default, the inter-function delay is set to zero. Enter a value, ranging from 0 to 254 in units of millisecond, to match the computer response time of the keyboard interface. Such delay time is inserted between every function code (0x01 ~ 0x1F) being transmitted. The longer the delay time is, the slower the transmission speed will be.



### 2.1.11 INTER-CHARACTER DELAY


By default, the inter-character delay is set to zero. Enter a value, ranging from 0 to 254 in units of millisecond, to match the computer response time of the keyboard interface. Such delay time is inserted between every character being transmitted. The longer the delay time is, the slower the transmission speed will be.

### 2.1.12 SNIFF MODE (VIA CRADLE)

By default, this power-saving feature is enabled, meaning the scanner will listen to the wireless network at a reduced rate while connecting to the cradle.

## 2.2 RS-232

Connect the cradle to the serial port of the host computer using the RS-232 cable and join the power adaptor to the RS-232 connector. The associated RS-232 parameters must match those configured on the computer. The scanned data will be transmitted to the serial port.



### 2.2.1 BAUD RATE

By default, it is set 115200 bps for the baud rate setting. Select other value that matches your computer settings.

### 2.2.2 DATA BITS

By default, it is set 8 bits of data. Select 7 bits of data if necessary.

### 2.2.3 PARITY

By default, it is set no parity bit. Select other parity setting, even or odd parity bit.

### 2.2.4 STOP BIT

By default, it is set 1 stop bit. Select 2 stop bits if necessary.

### 2.2.5 FLOW CONTROL

By default, there is no flow control in use. Select the flow control (handshake) method.

Options	Description
<i>No</i>	No flow control
<i>Scanner Ready</i>	The scanner will activate the RTS signal upon powering on. After each good read, the scanner will then wait for the CTS signal to become active. Data will not be sent until the CTS signal becomes active.
<i>Data Ready</i>	The RTS signal will be activated after each good read. The scanner will then wait for the CTS signal to become active. Data will not be sent until the CTS signal becomes active.
<i>Inverted Data Ready</i>	It works the same as the Data Ready flow control, except that the RTS signal level is inverted.

### 2.2.6 INTER-FUNCTION DELAY

By default, the inter-function delay is set to zero. Enter a value, ranging from 0 to 254 in units of millisecond, to match the computer response time of the RS-232 interface. Such delay time is inserted between every function code (0x01 ~ 0x1F) being transmitted. The longer the delay time is, the slower the transmission speed will be.

### 2.2.7 INTER-CHARACTER DELAY

By default, the inter-character delay is set to zero. Enter a value, ranging from 0 to 254 in units of millisecond, to match the computer response time of the RS-232 interface. Such delay time is inserted between every character being transmitted. The longer the delay time is, the slower the transmission speed will be.

### 2.2.8 ACK/NAK TIMEOUT

By default, the scanner sends data to the host without waiting for an ACK/NAK response before sending more data. Enter a value, ranging from 1 to 99 in units of 0.1 second. If no response within the specified period of time, the scanner will attempt to send the same data three more times. If all the attempts fail without any notification, data loss will occur.

---

Note: We suggest that you enable the error beep so that you will be notified of such data loss and have the scanner re-read data.

---


### 2.2.9 ACK/NAK ERROR BEEP

By default, this function is disabled; we suggest enabling the error beep so that you will be notified of such data loss and have the scanner re-read data.

### 2.2.10 SNIFF MODE (VIA CRADLE)

By default, this power-saving feature is enabled, meaning the scanner will listen to the wireless network at a reduced rate while connecting to the cradle.

## 2.3 BLUETOOTH HID



### 2.3.1 KEYBOARD TYPE

By default, the keyboard type is set to PCAT (US). The following keyboard types are supported –

No.	Keyboard Type	No.	Keyboard Type
64	PCAT (US)	70	PCAT (UK)
65	PCAT (French)	71	PCAT (Belgium)
66	PCAT (German)	72	PCAT (Spanish)
67	PCAT (Italy)	73	PCAT (Portuguese)
68	PCAT (Swedish)	74	PS55 A01-2 (Japanese)
69	PCAT (Norwegian)	76	PCAT (Turkish)

### 3.2 KEYBOARD SETTINGS

Refer to [2.1 Keyboard Wedge](#). Please ignore Alphabets Layout and Alternate Composing for Bluetooth HID.

- ▶ Alphabets Layout
- ▶ Digits Layout
- ▶ Capital Lock Type
- ▶ Capital Lock Setting
- ▶ Alphabets Transmission
- ▶ Digits Transmission

Note: Bluetooth HID does not support these functions on PDAs – (1) Capital Lock Setting: Auto Detection (2) Digits Transmission: Numeric Key

#### 2.3.3 INTER-FUNCTION DELAY

By default, the inter-function delay is set to zero. Enter a value, ranging from 0 to 254, to match the computer response time of the keyboard interface. Such delay time is inserted between every function code (0x01 ~ 0x1F) being transmitted. The longer the delay time is, the slower the transmission speed will be.

Value	Delay Time	Value	Delay Time
0	Disable	195 ~ 204	200 millisecond
1 ~ 14	10 millisecond	205 ~ 214	210 millisecond
15 ~ 24	20 millisecond	215 ~ 224	220 millisecond
25 ~ 34	30 millisecond	225 ~ 234	230 millisecond
35 ~ 44	40 millisecond	235 ~ 244	240 millisecond
45 ~ 54	50 millisecond	245 ~ 254	250 millisecond
...	...		

#### 2.3.4 INTER-CHARACTER DELAY

By default, the inter-character delay is set to zero. Enter a value, ranging from 0 to 254 in units of millisecond, to match the computer response time of the keyboard interface. Such delay time is inserted between every character being transmitted. The longer the delay time is, the slower the transmission speed will be.

#### 2.3.5 AUTHENTICATION

When any changes are made to authentication and PIN code on the scanner side, you will have to remove the scanner from the paired device list (called unpairing) and go through the whole process to re-establish the connection.

The scanner allows up to 16 characters for a PIN code and provides two options for authentication:

#### Enable Authentication with Preset PIN

Select the check box of "Authentication", and enter exactly the same string in the "PIN Code" field as the preset PIN for your computer or PDA to connect to the scanner. If the PIN or passkey is incorrect, any connection attempt will be turned down by the scanner.

☒ Authentication

PIN Code :


#### Enable Authentication with Random PIN or No Authentication

By default, it is set to "No PIN or use random PIN", which depends on the setting of the target device. (No PIN = No authentication.)

☐ Authentication

Use random PIN

No PIN required



Note: When using Bluetooth HID, some device driver may not support pre-defined PIN code for authentication. In this case, make sure you cancel the check box of "Authentication" to have the scanner set to "No PIN or use random PIN" before pairing. While pairing, the host PIN code will be displayed on the computer screen. Have the scanner read the setup barcode "Enter PIN Code in Decimal" or "Enter PIN Code in Hexadecimal" to input the matching PIN code.

### 2.3.6 BROADCASTING

The scanner can be configured to hide itself from other devices equipped with *Bluetooth*® wireless technology. Simply disable the device name broadcasting setting so that it won't be discovered by any other computer or PDA. However, broadcasting must be enabled for establishing an initial connection with the scanner.

For example, you can disable device name broadcasting after successfully connecting the scanner to WorkStation1. Such connection will be maintained automatically unless the scanner is removed from the paired device list (called unpairing) by WorkStation1 or any changes made to authentication and the PIN code. If you want WorkStation2 to connect to the scanner, you will have to enable device name broadcasting first.

---

Note: By default, device name broadcasting is enabled (which is required for initial connection).

---

### 2.3.7 SNIFF MODE

By default, this power-saving feature is enabled, meaning the scanner will listen to the wireless network at a reduced rate.

---

Note: When connecting more than two scanners to a notebook computer or PDA with *Bluetooth*® wireless technology, we suggest that you disable the power-saving setting for a more reliable connection.


---

### 2.3.8 CHARACTER TRANSMIT MODE

By default, HID interface sends data to the host in batch. You may change it to process data one character at a time.



## 2.4 BLUETOOTH SPP SLAVE MODE




### 2.4.1 AUTHENTICATION

When any changes are made to authentication and PIN code on the scanner side, you will have to remove the scanner from the paired device list (called unpairing) and go through the whole process to re-establish the connection. The scanner allows up to 16 characters for a PIN code and provides two options for authentication:


#### Enable Authentication with Preset PIN

Select the check box of "Authentication", and enter exactly the same string in the "PIN Code" field as the preset PIN for your computer or PDA to connect to the scanner. If the PIN or passkey is incorrect, any connection attempt will be turned down by the scanner.



### Enable Authentication with Random PIN or No Authentication

By default, it is set to "No PIN or use random PIN", which depends on the setting of the target device. (No PIN = No authentication.)



Note: When using Bluetooth HID, some device driver may not support pre-defined PIN code for authentication. In this case, make sure you cancel the check box of "Authentication" to have the scanner set to "No PIN or use random PIN" before pairing. While pairing, the host PIN code will be displayed on the computer screen. Have the scanner read the setup barcode "Enter PIN Code in Decimal" or "Enter PIN Code in Hexadecimal" to input the matching PIN code.

### 2.4.2 DEVICE NAME BROADCASTING

The scanner can be configured to hide itself from other devices equipped with *Bluetooth*® wireless technology. Simply disable the device name broadcasting setting so that it won't be discovered by any other computer or PDA. However, broadcasting must be enabled for establishing an initial connection with the scanner.

For example, you can disable device name broadcasting after successfully connecting the scanner to WorkStation1. Such connection will be maintained automatically unless the scanner is removed from the paired device list (called unpairing) by WorkStation1 or any changes made to authentication and the PIN code. If you want WorkStation2 to connect to the scanner, you will have to enable device name broadcasting first.

Note: By default, device name broadcasting is enabled (which is required for initial connection).

### 2.4.3 SNIFF MODE

By default, this power-saving feature is enabled, meaning the scanner will listen to the wireless network at a reduced rate.

Note: When connecting more than two scanners to a notebook computer or PDA with *Bluetooth®* wireless technology, we suggest that you disable the power-saving setting for a more reliable connection.

### 2.4.4 INTER-FUNCTION DELAY

By default, the inter-function delay is set to zero. Enter a value, ranging from 0 to 254, to match the computer response time of the Bluetooth SPP interface. Such delay time is inserted between every function code (0x01 ~ 0x1F) being transmitted. The longer the delay time is, the slower the transmission speed will be.

Value	Delay Time	Value	Delay Time
0	Disable	195 ~ 204	200 millisecond
1 ~ 14	10 millisecond	205 ~ 214	210 millisecond
15 ~ 24	20 millisecond	215 ~ 224	220 millisecond
25 ~ 34	30 millisecond	225 ~ 234	230 millisecond
35 ~ 44	40 millisecond	235 ~ 244	240 millisecond
45 ~ 54	50 millisecond	245 ~ 254	250 millisecond
...	...		

### 2.4.5 ACK/NAK TIMEOUT

By default, the scanner sends data to the host without waiting for an ACK/NAK response before sending more data. Enter a value, ranging from 1 to 99 in units of 0.1 second. If no response within the specified period of time, the scanner will attempt to send the same data three more times. If all the attempts fail without any notification, data loss will occur.

Note: We suggest that you enable the error beep so that you will be notified of such data loss and have the scanner re-read data.

### 2.4.6 ACK/NAK ERROR BEEP


By default, this function is disabled; we suggest enabling the error beep so that you will be notified of such data loss and have the scanner re-read data.

## 2.5 BLUETOOTH SPP MASTER MODE

In this mode, re-connection is made easy and reliable, just like connecting with the cradle. That is, as a SPP master device, the scanner will resume connection with the host upon powering on again, as long as the host application is running. You will hear three short beeps, tone ascending from low to high. If the scanner fails to resume connection, it will try every 5 seconds to re-connect to the host unless you change the interface to Bluetooth SPP Slave and download settings to the scanner.

Note: One alternative to stopping re-connection is to have the scanner read the "Reset Connection" or "Restore System Defaults" label. Refer to a separate manual for instructions.

For the connection settings, refer to [2.4 Bluetooth SPP Slave Mode](#).



Note: In SPP Master Mode, if it fails to re-connect within the specified period of time (2 minutes by default), the scanner will become inactive to save power. Once the re-connection is established successfully, the scanner will not go through transition from full CPU speed to low CPU speed even though it is idle during the specified time interval for Auto Power Off. It will automatically turn off when the time is up. Refer to [1.2 Power Management](#).

### How to connect with the target device?

---

Produce two setup labels for the target SPP slave device, just like what we do for the cradle.

- ▶ "Set Connection" label
- ▶ "MAC Address" label

Usage:

1. Change the interface to Bluetooth SPP Master and download settings to the scanner.
2. Click the field of "MAC Address of Remote Device" to choose characters from the pop-up window of Grid Control (see [Appendix I Grid Control](#)). It requires 12 characters.
3. Click [OK] to complete all the settings.
4. Go to **Download | Print scanner settings** to produce the "Set Connection" and "MAC Address" labels for printout.
5. Have the scanner read the "Set Connection" and "MAC Address" labels. It will respond with one beep upon reading each of the labels.

---

Note: (1) It will automatically add a prefix of "0x" to the real MAC address of the target device.  
(2) Read the "Set Connection" label first, and then the "MAC Address" label within 10 seconds.

---

### Switch between Master/Slave Mode

---

After the scanner has established a connection as a SPP slave device, change the interface to Bluetooth SPP Master and download settings to the scanner. It will work as a SPP master device then.

---

Note: Switching from SPP Slave to SPP Master does not require a new PIN code. You must leave it blank or enter exactly the same PIN code for SPP Slave; otherwise, it will fail to resume connection if a different PIN code is specified.

---


### Exit SPP Master Mode

---

To stop re-connection, change the interface to Bluetooth SPP Slave and download settings to the scanner. Alternatively, you may have the scanner read "Reset Connection" or "Restore System Defaults" label so that the current connection record (= MAC Address) will be cleared. Then, the scanner will restart itself automatically. Refer to a separate manual for instructions.


## 2.6 USB HID

For the connection settings, refer to [2.3 Bluetooth HID](#).



## 2.7 USB VIRTUAL COM

For the connection settings, refer to [2.4 Bluetooth SPP Slave Mode](#).








## CHANGING SYMBOLOGY SETTINGS

Barcode symbologies are application-dependent. You may enable or disable any of them, and configure their parameters according to the requirements of a specific application.



## IN THIS CHAPTER


---

3.1 Codabar.....	45
3.2 Code 25 — Industrial 25 .....	46
3.3 Code 25 — Interleaved 25.....	47
3.4 Code 25 — Matrix 25 .....	47
3.5 Code 39.....	48
3.6 Code 93.....	48
3.7 Code 128.....	48
3.8 EAN-8 .....	49
3.9 EAN-13.....	50
3.10 GS1-128 (EAN-128) .....	51
3.11 ISBT 128 .....	51
3.12 MSI.....	52
3.13 French Pharmacode .....	53
3.14 Italian Pharmacode.....	53
3.15 Plessey .....	54
3.16 GS1 DataBar (RSS Family) .....	55
3.17 Telepen .....	57
3.18 UPC-A.....	58
3.19 UPC-E.....	59

### 3.1 CODABAR

By default, the scanner is set to read Codabar barcodes.

- Advanced settings are provided as shown below.



#### Start/Stop Character

Select one of the four different start/stop character pairs.

#### Transmit Start/Stop Character

Select the check box so that the selected start/stop characters will be included in the data being transmitted.

#### CLSI Conversion

Select the check box so that the start/stop characters will be stripped and a space will be inserted after the first, fifth, and tenth characters of a 14-character barcode.

- This applies to 14-character barcodes only; barcode length does not include the start and stop characters.

## 3.2 CODE 25 – INDUSTRIAL 25

By default, the scanner is set to read Industrial 25 barcodes.

- ▶ Advanced settings are provided as shown below.

### Start/Stop Selection

Select a desired start/stop pattern. For example, flight tickets actually use an Industrial 25 barcode but with Interleaved 25 start/stop pattern. In order to read this barcode, the start/stop pattern selection of Industrial 25 should set to Interleaved 25.

### Verify Check Digit

Select the check box so that the scanner will verify check digit when decoding Industrial 25 barcodes. If the check digit is incorrect, the barcode will not be accepted.

### Transmit Check Digit

The check digit will be included in the data being transmitted.

Cancel the check box if the check digit is not desired.

### Length Qualification


Because of the weak structure of the 2 of 5 barcodes, it is possible to make a "short scan" error. To prevent the "short scan" error, configure the "Length Qualification" settings to ensure that the correct barcode is read by qualifying the allowable code length. The barcode can be qualified by "Fixed Length" or "Max/Min Length".

- ▶ For "Fixed Length", up to 2 fixed lengths can be specified.
- ▶ For "Max/Min Length", the maximum length and the minimum length must be specified. The scanner will only accept those barcodes with lengths that fall between max/min lengths specified.

### 3.3 CODE 25 – INTERLEAVED 25

By default, the scanner is set to read Interleaved 25 barcodes.

- ▶ Advanced settings are provided as shown below. Refer to Industrial 25.




The 'Interleaved 25 Parameters' dialog box contains the following settings:

- Start / Stop Selection:**
  - ☐ Industrial 25
  - ☒ Interleave 25
  - ☐ Matrix 25
- Length Qualification:**
  - ☐ Fixed Length
  - ☒ Max / Min Length
- ☐ Verify Check Digit
- ☒ Transmit Check Digit
- Max Length:** 126
- Min Length:** 4
- Buttons:** OK, Cancel

### 3.4 CODE 25 – MATRIX 25

Select the check box so that the scanner can read Matrix 25 barcodes.

- ▶ Advanced settings are provided as shown below. Refer to Industrial 25.




The 'Matrix 25 Parameters' dialog box contains the following settings:

- Start / Stop Selection:**
  - ☐ Industrial 25
  - ☐ Interleave 25
  - ☒ Matrix 25
- Length Qualification:**
  - ☐ Fixed Length
  - ☒ Max / Min Length
- ☐ Verify Check Digit
- ☒ Transmit Check Digit
- Max Length:** 127
- Min Length:** 4
- Buttons:** OK, Cancel

### 3.5 CODE 39

By default, the scanner is set to read Code 39 barcodes.

- ▶ Advanced settings are provided as shown below.



#### Code 39 Full ASCII

Select the check box so that the scanner will support Code 39 Full ASCII that includes all the alphanumeric and special characters.

#### Transmit Start/Stop

Select the check box so that the start/stop characters will be included in the data being transmitted.

#### Verify Check Digit

Select the check box so that the scanner will verify check digit when decoding Code 39 barcodes. If the check digit is incorrect, the barcode will not be accepted.

#### Transmit Check Digit

The check digit will be included in the data being transmitted.

Cancel the check box if the check digit is not desired.

### 3.6 CODE 93

By default, the scanner is set to read Code 93 barcodes.

- ▶ No advanced settings are available.

### 3.7 CODE 128

By default, the scanner is set to read Code 128 barcodes.


- ▶ No advanced settings are available.

### 3.8 EAN-8

By default, the scanner is set to read EAN-8 barcodes. (= No Addon)

Options of 2-digit and 5-digit extensions are available. Select the check box so that it can read Addon 2 and/or Addon 5.

- ▶ Advanced settings are provided as shown below.



#### EAN-8 Family

Select the check box to enable at least one type of the EAN-8 barcodes.

- ▶ EAN-8 (No Addon)
- ▶ EAN-8 Addon 2
- ▶ EAN-8 Addon 5

#### Convert to EAN-13

Select the check box so that the EAN-8 reading will be expanded into EAN-13. It will then be treated as an EAN-13 barcode and processed according to the settings of EAN-13.

#### Transmit Check Digit

The check digit will be included in the data being transmitted.


Cancel the check box if the check digit is not desired.

### 3.9 EAN-13

By default, the scanner is set to read EAN-13 barcodes. (= No Addon)

Options of 2-digit and 5-digit extensions are available. Select the check box so that it can read Addon 2 and/or Addon 5.

- ▶ Advanced settings are provided as shown below.



#### EAN-13 Family

Select the check box to enable at least one type of the EAN-13 barcodes.

- ▶ EAN-13 (No Addon)
- ▶ EAN-13 Addon 2
- ▶ EAN-13 Addon 5

#### ISBN Conversion

Select the check box so that the reading of EAN-13 barcodes that starts with 978 and 979 will be converted to ISBN.

#### ISSN Conversion

Select the check box so that the reading of EAN-13 barcodes that starts with 977 will be converted to ISSN.

#### Transmit Check Digit

The check digit will be included in the data being transmitted.

Cancel the check box if the check digit is not desired.

#### Security Level


Select the security level for reading EAN-13 barcodes. High security results in slow reading speed. You will have to compromise between security and decoding speed.



### 3.10 GS1-128 (EAN-128)

Select the check box so that the scanner can read GS1-128 (also known as EAN-128) barcodes.

- ▶ Advanced settings are provided as shown below.



#### Transmit Code ID

Select the check box so that the default Code ID ("]C1") will be included in the data being transmitted.

#### Field Separator

The FNC1 character is used to separate fields in the barcode. It is not represented in the readable text. To replace the FNC1 character with readable characters, click the field and choose characters from the pop-up window of Grid Control (see [Appendix I Grid Control](#)).

- ▶ Up to 2 characters can be chose from the Grid Control.

### 3.11 ISBT 128

By default, the scanner is set to read ISBT 128 barcodes.

- ▶ No advanced settings are available.

### 3.12 MSI

Select the check box so that the scanner can read MSI barcodes.

- ▶ Advanced settings are provided as shown below.

#### Check Digit Verification

Select the calculation used to verify MSI barcodes. If the check digit is incorrect, the barcode will not be accepted.

#### Check Digit Transmission

Select the way the check digits will be included in the data being transmitted.

#### Length Qualification

Because of the weak structure of MSI barcodes, it is possible to make a "short scan" error. To prevent the "short scan" error, configure the "Length Qualification" settings to ensure that the correct barcode is read by qualifying the allowable code length. The barcode can be qualified by "Fixed Length" or "Max/Min Length".


- ▶ For "Fixed Length", up to 2 fixed lengths can be specified.
- ▶ For "Max/Min Length", the maximum length and the minimum length must be specified. The scanner will only accept MSI barcodes with lengths that fall between max/min lengths specified.

### 3.13 FRENCH PHARMACODE

Select the check box so that the scanner can read French Pharmacode barcodes.

- ▶ Advanced settings are provided as shown below.

Check digit verification will be performed when decoding French Pharmacode because a check digit is always included. However, it is optional to transmit the check digit.



#### Transmit Check Digit

The check digit will be included in the data being transmitted.

Cancel the check box if the check digit is not desired.


Note: These barcodes share the **Transmit Start/Stop** setting with Code 39.

### 3.14 ITALIAN PHARMACODE

Select the check box so that the scanner can read Italian Pharmacode barcodes.

- ▶ Advanced settings are provided as shown below.

Check digit verification will be performed when decoding Italian Pharmacode because a check digit is always included. However, it is optional to transmit the check digit.



#### Transmit Check Digit

The check digit will be included in the data being transmitted.


Cancel the check box if the check digit is not desired.

Note: These barcodes share the **Transmit Start/Stop** setting with Code 39.

### 3.15 PLESSEY

Select the check box so that the scanner can read Plessey barcodes.

- ▶ Advanced settings are provided as shown below.




<b>Convert to UK Plessey</b>
Select the check box so that the scanner will change each occurrence of the character "A" to character "X" in the barcodes.
<b>Transmit Check Digit</b>
The two check digits will be included in the data being transmitted. Cancel the check box if the check digits are not desired.

### 3.16 GS1 DATABAR (RSS FAMILY)

Select the check box so that the scanner can read GS1 DataBar (also known as RSS) barcodes.

- ▶ Advanced settings are provided as shown below.



#### GS1 DataBar (RSS Family)

Select the check box to enable at least one type of the GS1 DataBar barcodes.

- ▶ GS1 DataBar Omnidirectional & Expanded
- ▶ GS1 DataBar Limited

#### Code ID Selection

By default, the Code ID of GS1 DataBar (RSS) barcodes is "]e0". You may select to use "]C1" instead.

- ▶ "]C1" is the Code ID of GS1-128 (EAN-128) barcodes.

#### Transmit Code ID

The selected Code ID will be included in the data being transmitted.

Cancel the check box if the Code ID is not desired.

#### Transmit Application ID

The Application ID will be included in the data being transmitted.


Cancel the check box if the Application ID is not desired.

<b>Transmit Check Digit</b>
The check digit will be included in the data being transmitted. Cancel the check box if the check digit is not desired.

### 3.17 TELEPEN

Select the check box so that the scanner can read Telepen barcodes.

- ▶ Advanced settings are provided as shown below.



#### Telepen Full ASCII or Numeric


Select whether AIM Telepen (Full ASCII) or Original Telepen (Numeric) is supported.

### 3.18 UPC-A

By default, the scanner is set to read UPC-A barcodes. (= No Addon)

Options of 2-digit and 5-digit extensions are available. Select the check box so that it can read Addon 2 and/or Addon 5.

- ▶ Advanced settings are provided as shown below.



#### UPC-A Family

Select the check box to enable at least one type of the UPC-A barcodes.

- ▶ UPC-A (No Addon)
- ▶ UPC-A Addon 2
- ▶ UPC-A Addon 5

#### Convert to EAN-13

Select the check box so that the UPC-A reading will be expanded into EAN-13. It will then be treated as an EAN-13 barcode and processed according to the settings of EAN-13.

#### Transmit Check Digit

The UPC-A check digit will be included in the data being transmitted.

Cancel the check box if the check digit is not desired.

#### Transmit System Number

The system number will be included in the data being transmitted.

Cancel the check box if the system number is not desired.




### 3.19 UPC-E

By default, the scanner is set to read UPC-E barcodes. (= No Addon)

Options of 2-digit and 5-digit extensions are available. Select the check box so that it can read Addon 2 and/or Addon 5.

- ▶ Advanced settings are provided as shown below.



#### UPC-E Family

Select the check box to enable at least one type of the UPC-E barcodes.

- ▶ UPC-E (No Addon)
- ▶ UPC-E Addon 2
- ▶ UPC-E Addon 5

#### System Number

By default, the scanner is set to read the ordinary UPC-E barcodes (= UPC-E0 only). You may change it to read both UPC-E0 and UPC-E1 barcodes.

#### Convert to UPC-A

Select the check box so that the UPC-E reading will be expanded into UPC-A. It will then be treated as a UPC-A barcode and processed according to the settings of UPC-A.

#### Transmit System Number

Select the check box so that the system number will be included in the data being transmitted.

#### Transmit Check Digit

The check digit will be included in the data being transmitted.

Cancel the check box if the check digit is not desired.



## DEFINING OUTPUT FORMAT

---

You may configure in which format the collected data will be output to the host computer. Barcode read by the scanner will be processed in the following sequence –

- 1) Perform character substitution on the data scanned.
- 2) Add [Code ID](#) and [Code Length](#) to the front of the data: [Code ID][Length Code][Data]
- 3) Process the whole data in step 2 with user formats. Data is now divided into fields by user specified rules.
- 4) Add [Prefix Code](#) and [Suffix Code](#) before transmission: [Prefix Code][Processed Data][Suffix Code]

Refer to [How to Configure the Scanner](#) for the flow chart of data process.


### IN THIS CHAPTER

---

4.1 Letter Case .....	62
4.2 Character Substitution .....	63
4.3 Prefix/Suffix Code .....	65
4.4 Code ID .....	66
4.5 Code Length .....	69
4.6 Output Sequence (Multi-Barcode Editor) .....	70
4.7 Remove Special Character .....	72

## 4.1 LETTER CASE

By default, the alphabets transmission is case-sensitive, meaning that the alphabets will be transmitted according to their original case. Ignoring the original letter case, select [Upper Case] to output data in upper case only; otherwise, select [Lower Case] to output data in lower case only.




## 4.2 CHARACTER SUBSTITUTION

Character substitution is performed on every occurrence of the first character entered. Click the field to choose characters from the pop-up window of Grid Control (see [Appendix I Grid Control](#)). If only one character is entered, every occurrence of that character in the barcode will be taken away.

- ▶ The first character will be replaced by the second character(s).
- ▶ Up to three sets of character substitution can be configured.

Note: The character substitution is performed only on the barcode itself and before the processing of editing formats. It is not applicable to the Prefix/Suffix Code, Code ID, Length Code, or any Additional Field.



If "Keyboard Wedge", "BT HID" or "USB HID" is configured for interface, Key Type and Key Status will then become applicable. Decide whether or not to apply Key Status when "Normal Key" is selected for Key Type.

Key Type	Key Status
<a href="#">Scan Code</a>	N/A
<a href="#">Normal Key</a>	<ul style="list-style-type: none"><li>▶ Add Shift</li><li>▶ Add Left Ctrl</li><li>▶ Add Left Alt</li><li>▶ Add Right Ctrl</li><li>▶ Add Right Alt</li><li>▶ Add Break</li></ul> <p>For example, choose [A], and then select one of the above keys, say, [Add Shift], and choose the character [B] from the Grid Control. It will replace the character [A] with [Shift+B].</p>

---

Note: It only allows choosing one scan code value. However, you may choose an ASCII character, and then switch from "Normal Key" to "Scan Code" and choose a scan code to replace the ASCII character with scan code value.

---

#### 4.2.1 APPLICABLE CODE TYPES

By default character substitution will be performed on all symbologies. If it is not desired with one or more symbologies, click this button and then cancel the check box of each undesired symbologies and all the three sets will not be applied to them.

### 4.3 PREFIX/SUFFIX CODE

Click the Prefix Code or Suffix Code field so that you can choose characters from the pop-up window of Grid Control (see [Appendix I Grid Control](#)).

- ▶ Prefix Code: None
- ▶ Suffix Code: By default, [ENTER] or [CR] (Carriage Return) is entered.


Originally, "Normal Key" is in use by default, Up to eight characters can be chose from the Grid Control. For example, "Barcode\_", and you will have the string appear in front of the barcode read, like this — "Barcode\_1234567890".

If "Keyboard Wedge", "BT HID" or "USB HID" is configured for interface, Key Type and Key Status will then become applicable. Decide whether or not to apply Key Status when "Normal Key" is selected for Key Type.

Key Type	Key Status
<a href="#">Scan Code</a>	N/A
<a href="#">Normal Key</a>	<ul style="list-style-type: none"> <li>▶ Add Shift</li> <li>▶ Add Left Ctrl</li> <li>▶ Add Left Alt</li> <li>▶ Add Right Ctrl</li> <li>▶ Add Right Alt</li> <li>▶ Add Break</li> </ul> <p>For example, select one of the above keys, say, [Add Shift], and choose the character [A] from the Grid Control.</p>

## 4.4 CODE ID

To make the Code ID configuration easier, we provide five pre-defined Code ID sets that you can make necessary changes.



The image shows a 'Scanner Settings' dialog box with the 'Code ID' tab selected. The tab is highlighted with a red rectangle. The dialog contains a table of barcode symbologies and their corresponding Code IDs, each with a text input field. Below the table are buttons for 'Set 1' through 'Set 5' and a 'Clear' button. At the bottom are 'OK' and 'Cancel' buttons.

Symbology	Code ID
Code 39	[A]
Italian Pharmacode	[A]
French Pharmacode	[A]
Industrial 25	[C]
Interleaved 25	[D]
Matrix 25	[E]
Codabar	[F]
Code 93	[I]
ISBT 128	[H]
Code 128	[H]
EAN 8	[S]
EAN 13	[P]
UPCA	[M]
UPCE	[J]
MSI	[V]
Plessey	[W]
Telepen	[Z]

Set 1 Set 2 Set 3 Set 4 Set 5 Clear

OK Cancel

Note: "[C1]" is the Code ID of GS1-128 (EAN-128) barcodes; "[e0]" is the default Code ID of GS1 DataBar (RSS) barcodes.



## 4.4.1 CODE ID SET 1~5

Code ID options	Set 1	Set 2	Set 3	Set 4	Set 5
<i>Code 39</i>	A	C	Y	M	A
<i>Italian Pharmacode</i>	A	C	Y	M	A
<i>French Pharmacode</i>	A	C	Y	M	A
<i>Industrial 25</i>	C	H	H	H	S
<i>Interleaved 25</i>	D	I	Z	I	S
<i>Matrix 25</i>	E	G	G	G	S
<i>Codabar</i>	F	N	X	N	F
<i>Code 93</i>	I	L	L	L	G
<i>ISBT 128</i>	H	K	K	K	C
<i>Code 128</i>	H	K	K	K	C
<i>UPC-E</i>	S	E	C	E	E
<i>EAN-8</i>	P	B	B	FF	E
<i>EAN-13</i>	M	A	A	F	E
<i>UPC-A</i>	J	A	A	A	E
<i>MSI</i>	V	V	D	P	M
<i>Plessey</i>	W	W	E	Q	P
<i>Telepen</i>	Z	---	---	---	---

#### 4.4.2 CHANGE CODE ID

To modify the Code ID, click the field next to a symbology. Then, choose your Code ID from the pop-up window of Grid Control (see [Appendix I Grid Control](#)).

Up to two characters for Code ID can be configured for each symbology.

If "Keyboard Wedge", "BT HID" or "USB HID" is configured for interface, Key Type and Key Status will then become applicable. Decide whether or not to apply Key Status when "Normal Key" is selected for Key Type.


Key Type	Key Status
<a href="#">Scan Code</a>	N/A
<a href="#">Normal Key</a>	<div><div>▶ Add Shift</div><div>▶ Add Left Ctrl</div><div>▶ Add Left Alt</div><div>▶ Add Right Ctrl</div><div>▶ Add Right Alt</div><div>▶ Add Break</div></div> <div>For example, select one of the above keys, say, [Add Shift], and choose the character [A] from the Grid Control.</div>

#### 4.4.3 CLEAR

Click this button to clear the current settings. Default settings will be loaded. That is, the Code ID settings are empty.

## 4.5 CODE LENGTH

A two-digit code representing the length of barcode data (character count) can be inserted in front of data being transmitted. Such length code can be individually enabled or disabled for each symbology. By default, no length code is added to output data for all symbologies.



## 4.6 OUTPUT SEQUENCE (MULTI-BARCODE EDITOR)

The Multi-Barcode Editor allows you to decide the output sequence of a concatenation of barcodes.

---


Note: The Multi-Barcode Editor has nothing to do with Multi-Barcode Mode.

---

By default, the output sequence editing of the concatenation of barcodes is not applied – “Ignored”. When “Enforce” is selected, all barcodes read by the scanner must meet with the criteria for the concatenation. If data is found excluded from all output sequence sets (= not meeting with the criteria), the scanner will not accept the reading, and therefore, data will not be transmitted. When “Apply” is selected, only barcodes found meeting with the criteria are counted for the concatenation. Those found not meeting with the criteria are processed normally and individually.


The barcodes that are found meeting the specified criteria below will be arranged in the desired sequence.

- ▶ Code Type
- ▶ Barcode length, excluding prefix, suffix, length code, etc. — set “0” to ignore length.
- ▶ Matching the first character of data — leave it blank to ignore character matching.



## 4.7 REMOVE SPECIAL CHARACTER

You can only specify 1 character, but it will remove every matching character encountered from the starting position of barcode data until a different character is met. For example, if it is specified to remove the character "0", one or more zeros will be stripped off the barcode data "012345" and "00012345". However, for barcode data "010333", only the first zero will be stripped off.



APPLYING EDITING FORMATS

---

The scanner allows advanced data editing by applying user-configured editing formats. Data is divided into fields by user-specified rules. These fields together with the user-configurable additional fields consist of the data actually sent to the host computer.

- ▶ Up to five different formats can be specified.

IN THIS CHAPTER

---

5.1 Format Selection ..... 74

5.2 Configure Editing Format ..... 75

## 5.1 FORMAT SELECTION


### 5.1.1 ENABLE EDITING FORMATS

If you have already configured any editing format before, you may directly apply the editing format. If not, you must start with configuring an editing format first, and then, select the check box to enable any of the five editing formats when it is desired in use.

### 5.1.2 EXCLUSIVE DATA EDITING

By default, only barcodes found meeting with the criteria are processed by the editing formats. Those found not meeting with the criteria are processed normally.

Select the check box to apply "Exclusive Data Editing". When applied, all barcodes read by the scanner must be processed by the editing formats. If data is found excluded from all enabled editing formats (= not meeting with the specified criteria), the scanner will not accept the reading, and therefore, data will not be transmitted.






## 5.2 CONFIGURE EDITING FORMAT

Three applicable conditions can be configured to check whether the data read by the scanner can be processed by a particular editing format.

Note: Data editing cannot be performed unless the three conditions are all met.

### 5.2.1 APPLICABLE CONDITIONS



#### Applicable Code Type

By default, barcodes of all the supported symbologies are eligible for data editing.

- ▶ Cancel the check box next to a symbology for which data editing is not desired.

#### Data Length

The length must include prefix, suffix (0x0d by default), length code, etc. By default, barcodes with length (character count) ranging from 0 to 127 are eligible for data editing.


- ▶ Enter a value from 0 to 254.
- ▶ When zero is given to both, the scanner will not perform the length qualification.

### Matching String & Location

By default, no matching string is entered, and therefore, it is disabled. You may enable this feature by entering a matching string. Choose up to four characters from the pop-up window of Grid Control (see [Appendix I Grid Control](#)).

- ▶ When the Matching String Location is zero, the scanner will only check for the existence of the matching string in the barcode data.
- ▶ Enter a value from 1 to 254 to indicate where the matching string starts in the barcode data.

## 5.2.2 FIELD SETTINGS



### Number of Fields

Data can be divided into at most 6 fields; each of them is numbered from F1 to F6 accordingly. However, only F1~F5 can be configured.

- ▶ The total number of fields must be entered correctly. If three fields are configured for the editing format, the data characters after F3 will be assigned to F4 automatically. This feature is quite useful especially when data of variable lengths is processed by editing formats.

**Length Adjustment**

You may apply equal length to all fields, if necessary. Select the check box and enter a desired length. It will add "Space" (0x20) to field when data is found shorter than specified.

**Field Separation Direction**

Data can be divided into fields in one of the following direction –

- ▶ from head (F1) to tail (F5)
- ▶ from tail (F1) to head (F5)

**Pause Field Time (sec)**

You can limit the pause time interval (1~16). By default, it is set to 1 second.

**Field Setting**

Data eligible for editing formats is divided into fields by user-specified rules – either using the field terminating string or specified field length.

Enter the field terminating string. Choose up to two characters from the pop-up window of Grid Control (see [Appendix I Grid Control](#)). The scanner will search for the occurrence of this particular string in the data. Alternatively, you may simply enter the field length. The scanner will assign the next specified number of characters into the field.

- ▶ By default, this terminating string, if exists, will be included in the field. If you wish to discard it, cancel the check box.


**Additional Fields**

Up to five additional fields can be created for each editing format; each of them is numbered from AF1 to AF5 accordingly. To configure the Additional Fields setting, click the associated field and choose up to four characters from the pop-up window of Grid Control (see [Appendix I Grid Control](#)).

**Note:** The number of configurable fields is always one less than the total number of fields specified. The extra data characters beyond the last field configured will be automatically assigned to the next field.

### 5.2.3 TRANSMISSION SEQUENCE

After configuring the data fields and additional fields, user can now program the transmission sequence of these fields that comprise the final data. Simply click on the buttons of these fields in sequence, and they will appear in the Transmission Sequence field. This field transmission sequence can be assigned in any desired order and fields can be assigned multiple times as well. The maximum number of fields can be assigned is twelve.




## 5.2.4 EXAMPLES

**Example 1 – Extract data from the 10th character to the 19th character...**

The editing format should be configured as follows:

1. Set Number of Fields to "3".
2. Set Field1 Parameters: divide field by Length, and set length to "9".  
Field1 = from the 1th character to the 9th character
3. Set Field2 Parameters: divide field by Length, and set length to "10".  
Field2 = from the 10th character to the 19th character
4. Set Transmission Sequence to transmit "F2" only.



**Example 2 – Extract the date code, item number, and quantity information from barcodes.**

Data is encoded in the barcode like this:


- From the 1st character to the 6th character is the date code.
- From the 7th character to the "-" character is the item number.
- After the "-" character is the quantity information.

Data will be transmitted like this:

- The item number goes first, then a TAB character, followed by the date code, then another TAB character, and finally the quantity information.

The editing format should be configured as follows:

1. Set Number of Fields to "3".
2. Set Field1 Parameters: divide field by Length, and set length to "6".  
Field1 = from the 1th character to the 6th character
3. Set Field2 Parameters: divide field by Terminating String, and set the string to "-".  
Field2 = from the 7th character to the "-" character
4. Set Additional Field 1 to one "TAB" character.
5. Set Transmission Sequence to transmit "F2 A1 F1 A1 F3".







## GRID CONTROL

### ORIGINAL GRID CONTROL

This is used for the following settings:

- ▶ MAC address for Bluetooth SPP Master
- ▶ Field Separator for GS1-128
- ▶ Remove Special Character

The Grid Control
✕

	00	10	20	30	40	50	60	70
00		DLE	Space	0	@	P	`	p
01	SOH	DC1	!	1	A	Q	a	q
02	STX	DC2	"	2	B	R	b	r
03	ETX	DC3	#	3	C	S	c	s
04	EOT	DC4	\$	4	D	T	d	t
05	ENQ	NAK	%	5	E	U	e	u
06	ACK	SYN	&	6	F	V	f	v
07	BEL	ETB	'	7	G	W	g	w
08	BS	CAN	[	8	H	X	h	x
09	HT	EM	]	9	I	Y	i	y
0A	LF	SUB	*	:	J	Z	j	z
0B	VT	ESC	+	;	K	[	k	{
0C	FF	FS	,	<	L	\	l	
0D	CR	GS	-	=	M	]	m	}
0E	SO	RS	.	>	N	^	n	~
0F	SI	US	/	?	O	_	o	DEL

Resulting text :

Clear

OK

Cancel

Note: For a TAB character, click "HT".

## SPECIAL GRID CONTROL FOR KEYBOARD INTERFACE

This is used for the following settings:

- ▶ Character Substitution
- ▶ Prefix/Suffix Code
- ▶ Code ID
- ▶ Additional Fields for configuring editing format

Note: This is available only when "Keyboard Wedge", "BT HID" or "USB HID" is selected for interface.

### GRID CONTROL – NORMAL KEY

By default, each character programmed is a "Normal Key". Such a character can have associate status settings by adding the Shift/Control/Alternate keys.

**The Grid Control**

	00	10	20	30	40	50	60	70	80
00		F2	Space	0	@	P	`	p	0*
01	Insert	F3	!	1	A	Q	a	q	1*
02	Delete	F4	"	2	B	R	b	r	2*
03	Home	F5	#	3	C	S	c	s	3*
04	End	F6	\$	4	D	T	d	t	4*
05	Up	F7	%	5	E	U	e	u	5*
06	Down	F8	&	6	F	V	f	v	6*
07	Left	F9	'	7	G	W	g	w	7*
08	BS	F10	{	8	H	X	h	x	8*
09	HT	F11	}	9	I	Y	i	y	9*
0A	LF	F12	*	:	J	Z	j	z	
0B	Right	ESC	+	;	K	[	k	{	
0C	PgUp	Exec	,	<	L	\	l		
0D	Enter	Send	-	=	M	]	m	}	
0E	PgDn		.	>	N	^	n	~	
0F	F1		/	?	O	_	o	Delay	Enter*

Key Type:

☐ Scan Code

☒ Normal Key

Key Status:

☐ Add Shift

☐ Add Left Ctrl

☐ Add Left Alt

☐ Add Right Ctrl

☐ Add Right Alt

Resulting text :

[ \$ ]

OK Clear Cancel

Note: For a TAB character, click "HT".

For example, if you want to program "Ctrl-Shift-B", "C" for Prefix Code, the programming sequence is as follows:

- 1) Click the Prefix Code field.
- 2) Select "Normal Key" for Key Type in the Grid Control window.
- 3) Select the check box of "Add Left Ctrl" and "Add Shift" for Key Status.
- 4) Choose "B" from the ASCII table.
- 5) Cancel the check box of "Add Left Ctrl" and "Add Shift".
- 6) Choose "C" from the ASCII table.
- 7) Click [OK] to confirm the setting.

### GRID CONTROL – SCAN CODE

Select "Scan Code" so that the scanner is configured to program a character by its scan code value.

**The Grid Control**

	00	10	20	30	40	50	60	70	80	90	A0	B0	C0	D0	E0	F0
00	00	10	20	30	40	50	60	70	80	90	A0	B0	C0	D0	E0	F0
01	01	11	21	31	41	51	61	71	81	91	A1	B1	C1	D1	E1	F1
02	02	12	22	32	42	52	62	72	82	92	A2	B2	C2	D2	E2	F2
03	03	13	23	33	43	53	63	73	83	93	A3	B3	C3	D3	E3	F3
04	04	14	24	34	44	54	64	74	84	94	A4	B4	C4	D4	E4	F4
05	05	15	25	35	45	55	65	75	85	95	A5	B5	C5	D5	E5	F5
06	06	16	26	36	46	56	66	76	86	96	A6	B6	C6	D6	E6	F6
07	07	17	27	37	47	57	67	77	87	97	A7	B7	C7	D7	E7	F7
08	08	18	28	38	48	58	68	78	88	98	A8	B8	C8	D8	E8	F8
09	09	19	29	39	49	59	69	79	89	99	A9	B9	C9	D9	E9	F9
0A	0A	1A	2A	3A	4A	5A	6A	7A	8A	9A	AA	BA	CA	DA	EA	FA
0B	0B	1B	2B	3B	4B	5B	6B	7B	8B	9B	AB	BB	CB	DB	EB	FB
0C	0C	1C	2C	3C	4C	5C	6C	7C	8C	9C	AC	BC	CC	DC	EC	FC
0D	0D	1D	2D	3D	4D	5D	6D	7D	8D	9D	AD	BD	CD	DD	ED	FD
0E	0E	1E	2E	3E	4E	5E	6E	7E	8E	9E	AE	BE	CE	DE	EE	FE
0F	0F	1F	2F	3F	4F	5F	6F	7F	8F	9F	AF	BF	CF	DF	EF	FF

Key Type

☒ Scan Code

☐ Normal Key

Key Status

☐ Add Shift

☐ Add Left Ctrl

☐ Add Left Alt

☐ Add Right Ctrl

☐ Add Right Alt

Resulting text :

OK

Clear

Cancel