

CONNECTING THE METAPACE S-2 VIA BLUETOOTH (IPAD, PC, MOBILE PHONE, ETC.)

In order to connect the Metapace S-2 with a Bluetooth device, please follow the steps below:

1.  1.1

Enter Setup

 1.2

Restore Default Settings

Set the scanner to Bluetooth HID (German Layout)

Interface Settings : Bluetooth HID

2.  2.1

HID PCAT (German) 0x06

 2.2

 2.3

0x06

 2.4

Validate

 2.5

Update

3. Tell the scanner that there is no preset Bluetooth PIN, but that random PIN will be generated during the connection process:

 3.1

Enter Setup

 3.3

Validate

*No PIN or
use random PIN

 3.2

100154











 3.4

Update


The host should now be able to find the scanner. Please connect the scanner with the host now. The host should display a 4-character PIN. Please scan the barcodes below to enter the PIN.

4.
Enter PIN Code
in Decimal ...

100151

5.
0  109900  109901
2  109902  109903
4  109904  109905
6  109906  109907
8  109908  109909

Validate the Values

6.
Validate

109994

The configuration process is complete. The scanner and host device are connected.